



SP、SY Series PCB pins Rear-nut Socket Assembling Instruction

1, Unscrew the rear-nut.




SP/SY Series
Panel Cutout




		. =
Series	A(mm)	B(mm)
SP11/SY11	9.9	11
SP13	11.8	13
SP17	15.6	17
SP21	19.8	21
SP25/SY25	23.1	25
SP29	26.8	29.2
SY29	26.6	29.2

2. Put the socket into the panel based on Panel cutout size .




SY13/17/21 Panel Cutout




Series	A(mm)	B(mm)
SY13	12.3	13
SY17	16.1	17
SY21	20.2	21

3、 Tighten the rear-nut according to the below torque.




Series	Torque (N.M)
SP11/SY11/SP13/SY13	0.5-0.6
SP17/SY17	0.9-1
SP21/SY21/SP25/SY25	1-1.1
SP29/SY29	1-1.1

4. Align and install the PCB pins into the PCB board.



5. Solder the PCB tails on PCB board. **Note:** 1) The Iron cannot burn the board;

2) Ensure the pins do not exceed the board plane.



Caution:

Do NOT apply sealants on plastic connector housings, which may lead to connector breakage.

If sealing is required, please use **LOCTITE-403 instant adhesive** or **Kafuter K-704 silicone sealant** for material compatibility.