1

backshell

socket main part   compression nut

1. Unscrew each part of the socket.

2

2. Put the stripped RJ45 wire into the compression nut and backshell.

3

3. Assemble the RJ45 insert on cable

4

4. Install the assembled RJ45 insert into socket main part.

5

5.1.T ighten the main part and the backshell according to the torque of 1.0-1.2N.m. (tighten by mating with plug, can't use fixture)

5.2. Tighten the compression nut and the backshell according to the torque of 1.2-1.4N.m.