WEiPU® Connector

ST1212   WY12-ZM Rear-nut mount Socket Assembling Instruction-Solder

main part

locknut

cap

Panel cutout

11.5

φ12

① Strip length

5mm

20mm

Unscrew the locknut

③ Put the stripped wire throught the locknut and panel. (Panel thickness: 3.5mm max)

④ Solder the wire to the contact and wrap with heat shrinkable tube after soldering.

⑤ Install the socket on the panel closely

⑥ Tighten the locknut with torque of 0.3-0.5N.m