

## SA/SF6-8 rear-nut mount socket assembling instruction-Solder

① SA/SF6-8 Strip length

② Unscrew the locknut

③ Put the stripped cable through the locknut and panel (panel thickness: 2max)

④ Put the stripped wire into contact holes and wrap with heat shrinkable tube after soldering.

⑤ Tighten the socket body and panel closely

⑥ Tighten the locknut according to torque of 0.15-0.2N.m

Series	ΦA (mm)	B (mm)
SF6/SA6	6	5.7
SF8/SA8	8	7.7