WEiPU® Connector

SP1315 front-nut Socket Assembling Instruction

front-nut

Cap

Main part

O-ring

1. Strip length

25 4

2. Slide off the front-nut and cap

3. Solder the wire and then wrap it with a heat- shrinkable tube.

4. Put the socket into the panel.

Panel cutout: 16*14.8mm
Panel thickness: 4mm max

5. Install the panel and socket closly.

6.Tighten the front-nut according to torque of 0.8-1.0 N.m

https://www.weipuconnector.com/   E-mail:info@weipuconnector.com

Locknut

≤0.5mm

Note After mating the socket and plug,
the distance in between should be ≤0.5mm.

https://www.weipuconnector.com/ E-mail:info@weipuconnector.com